




WIRELESS PRESENTATION SYSTEMS

PRESENT POINT

WP-PP-01 / WP-PP-04 / WP-PP-09


(SHORT OPERATION GUIDE)



To connect to the PRESENT POINT base unit


- MAC (using WP-PP-USB wireless launcher)
 - Windows laptops (using WP-PP-USB wireless launcher)
1. Connect the HDMI or VGA cable to your device and display system (projector or TV panel).
 2. Plug the power connector into a wall outlet.
 3. Connect the WP-PP-USB wireless launcher to your computer or laptop:

- Open the My Computer folder



- open the ESHOW folder

- initialize WP-PP-USB wireless launcher (double click)




- The WP-PP-USB Wireless Launcher Initialization Window will appear in the lower right corner of your screen
- After initialization of the WP-PP-USB wireless launcher, the message "Connection open" will appear in the window
- Press the WP-PP-USB Wireless Launcher and work on the big screen
- Click on the WP-PP-USB wireless launcher again to disconnect from the large screen

To connect to the PRESENT POINT base unit

- MAC (using ESHOW virtual launcher)
 - Windows laptops (using ESHOW virtual launcher)
1. Connect the HDMI or VGA cable to your device and display system (projector or TV panel).
 2. Plug the power connector into a wall outlet.
 3. Install ESHOW Virtual Launcher on your computer. The program is available at: https://presentpoint.com.ua/ua/page/software/virtual_launcher_eshow.html

1. Connect to the base unit via WiFi:
- Find and connect to a device on WiFi networks




Password: 12345678


Start ESHOW Virtual Launcher




Connect to the device.



Work on the big screen by tapping on the icon



Tap the icon to disconnect from the large screen



If your device is integrated into your LAN, you can also connect to it using the ESHOW virtual launcher by entering the IP address of the device.




Integration of PRESENT POINT into LAN

LAN integration enables you to connect your smartphones or tablets through a Wi-Fi LAN hotspot without losing access to the Internet or internal corporate resources.

To connect to the PRESENT POINT base unit


- iOS and MAC devices (using Airplay)

1. Connect the HDMI or VGA cable to your device and display system (projector or TV panel).
2. Plug the power connector into a wall outlet.
3. Connect to the base unit via WiFi:
 - Find and connect to a device on WiFi networks



Password: 12345678

Open Control Center and apply the "Repeat Screen" icon



Work on the big screen

To connect to the PRESENT POINT base unit

- Android devices (using Eshow)

Connect the HDMI or VGA cable to your device and display system (projector or TV panel).

Plug the power connector into a wall outlet.

Download and install Eshow on your smartphone




Or at the link:

https://presentpoint.com.ua/ua/page/software/android_eshow.html


Connect to the base unit via WiFi:

- Find and connect to a device on WiFi networks



Password: 12345678

Open the Eshow app on your smartphone




- Tap the Media icon, you can share media content (audio or video).
 - Touch the Single View icon, you can only share your content.
- Work on the big screen

To connect to the base unit PRESENT POINT - login to the admin panel (advanced settings)

Connect to the base unit via WiFi:

- Find and connect to a device on WiFi networks



Password: 12345678

Contact Details:

Manufacturing company: IBEST OÜ (Kadaka tee 113a, 12915 Tallinn, Estonia)

The official representative of IT Business Solution LLC:

Legal address: Ukraine, 04050, Kiev., St. Melnikova, 12, tel. + 38-044-597-10-90

Actual address: Ukraine, 03164, city. Kiev, st. Buchanska 25/28, tel. + 38-044-597-10-90

The official service center of IT Business Solution LLC.: Ukraine, 03164, Kiev., st. Buchanska 25/28, tel. + 38-044-597-10-90

